GB50 12V 1500A 7.0L 4.5L

Lead Acid -Wet Gel MF **EFB** AGM Auto | Marine | RV | Powersport | Lawn & Garden

### XL<sup>™</sup>J UMP STARTER



# START DEAD BATTERIES."

Diesel Cars, SUVs, Boats, Motorcycles, ATVs, Trucks & More.

Ultra-safe, ultra-compact, rugged, and portable lithium-ion jump startep and technology and reverse polarity protection Instantly jump starts most single-battery application 6, times on a single charge. Ideal for a wide range of vehicles including small diesel cars, trucks and engine on the total diesel cars, trucks and engine of the total diesel cars, and the total diesel cars, trucks and engine of the total diesel cars, trucks and engine of the total diesel cars, and the total diesel cars,



Protects against reverse polarity, sparks, over-charging, over-current, open-circuits and over-heating.

Jump Starts Per Charge

to 30 times in one char@empable with engines up to 7.0L Gas and 4.5L Diesel.



Full power to jump start a vehicle up Recharge virtually any USB device unit from any USB port or 12V charger included.

Ultra-bright dual LED flashlight for (smartphones, tablets). Recharge the visibility and with 7 modes, uding SOS and emergency strobe.



## Advanced Protection.

Designed to protect your device.



 $Hot\ LED\ indicator Designed\ to\ indicate$ when internal battery approaches high

- Solid Red. Unit is fully operational, but approaching upper temperature limit.
- Flashing Red.Unit is too hot to jump start, but other functions are still available.

Cold LED indicator Designed to indicate when internal battery temperature is too cold to operate.

- Solid Blue. Unit is fully operational, but approaching lower temperature limit.
- Flashing Blue. Unit is too cold to jump start, but other functions are still available.



Smartphones and Tablets.



Error LED. Illuminates Red if reverse polarity is detected, or blinks "On" and "Off" when the internal battery temperature is too high.



Manual Overridels a special feature designed for rare situations when a vehicle's battery is below 2-volts. Simply press and hold the manual overide button for 3 seconds, until the Boost LED starts flashing, to enter into the mode. Press the button again (Or the power button) to exit Manual Override. This mode should be used cautiously, as Manual Override disables safety protection while enabled.

#### **Technical Specifications**

· ·			
Internal Battery:	Lithium Ion	Housing Protection:	IP65 (w/ Ports closed)
Peak Current Rating:	1500A	Cooling:	Natural Convection
Operating Temperature:	-4°F to +122°F (-20°C to +50°C)	Dimensions (LxWxH):	7.7 x 3.4 x 1.9 in
Charging Temperature:	0°F to +104°F (-18°C to +40°C)	Unit Weight:	1.65 Pounds
Storage Temperature:	-4°F to +122°F (-20°C to +50°C)	Unit Weight w/Clamps & Accessories:	2.71 Pounds
Micro USB (Input):	5V, 2.1A		
USB (Output):	5V, 2.1A	LED Flashlight Brightness:	200 Lumens

#### What's In The Box

- GB50 Boost XL Jump Starter
- 40" Micro USB Cable • 12V USB Charger
- HD Precision Boost Battery Clamps
- · User Guide & Warranty

Retail Packaging
Dimensions: 3.9"x4.7"x9.1
Wajaht, 2 22lbs

UPC: 0-46221-18017-6

Inner Carton: Dimensions: 4.1"x9.37"x5.27" Units Per Pallet: Weight: 3.5lbs

Master Carton: Dimensions: 10.25"x13.5"x11.375"

Weight: 22.07lbs Quantity: 6 UCC: 10046221180173

198 Units



Recharging a GB50

1A

**USB Charger Rating** 



(for reference,


**Charging Time** 

18hr

9hr

4.5h

results may vary)



#### NOCO

30339 Diamond Parkway, #102 Glenwillow, OH 44139 | USA 1.800.456.6626

no.co

